

2008, 2009, 2010, 2011 SOFTAIL MODEL SERVICE INTERVALS

| ITEM SERVICED | PROCEDURE | 1000 M | 5000 M | 10,000 M | 15,000 M | 20,000 M | 25,000 M | NOTES | COMPLETE | |
|---|---|---|--------|----------|----------|----------|----------|-------|----------|--|
| Engine oil and filter | Replace | X | X | X | X | X | X | | | |
| Oil lines and brake system | Inspect for leaks | X | X | X | X | X | X | 1 | | |
| Air cleaner | Inspect, service as required | X | X | X | X | X | X | | | |
| Tires | Check pressure, inspect tread | X | X | X | X | X | X | | | |
| Wheel spokes | Check tightness | X | X | X | X | X | X | | | |
| Primary chaincase lubricant | Replace | X | X | X | X | X | X | | | |
| Transmission lubricant | Replace | X | X | X | X | X | X | | | |
| Clutch | Check clutch adjustment | X | X | X | X | X | X | 1 | | |
| Rear belt and sprockets | Inspect, adjust belt | X | X | X | X | X | X | 1 | | |
| Throttle, brake, and clutch controls | Check, adjust and lubricate | X | X | X | X | X | X | 1 | | |
| Jiffy stand | Inspect and lubricate | X | X | X | X | X | X | 1 | | |
| Fuel lines and fittings | Inspect for leaks | X | X | X | X | X | X | 1 | | |
| Fuel tank filter | Replace | | | | | | X | 1 | | |
| Brake fluid | Check levels and condition | X | X | X | X | X | X | 6 | | |
| Brake pads and discs | Inspect for wear | X | X | X | X | X | X | | | |
| Spark plugs | Replace | X | X | X | X | X | X | | | |
| Electrical equipment and switches | Check operation | X | X | X | X | X | X | | | |
| Engine idle speed | Check adjustment | X | X | X | X | X | X | 1 | | |
| Front fork oil | Replace | Replace at 50,000 miles (80,000 kilometers) | | | | | | | 1 | |
| Steering head bearings (Softail models) | Lubricate | X | | X | | X | | 1 | | |
| | Adjust | | | X | | X | | 2 | | |
| Steering head bearings (Springer models) | Lubricate | Adjust and lubricate every 2,500 miles (4,000 kilometers) | | | | | | | 1,5 | |
| | Adjust | | | | | | | | | |
| Windshield bushings (if applicable) | Inspect | | | X | | X | | 1 | | |
| Springer rocker bearings | Adjust | X | | X | | X | | 1,7 | | |
| Critical Fasteners | Check tightness | X | X | X | X | X | X | 1 | | |
| Battery | Check and clean connections | X | X | X | X | X | X | 3 | | |
| Exhaust system | Inspect for leaks, cracks, and loose/missing fasteners and heat shields | X | X | X | X | X | X | 3 | | |
| Road test | Verify component and system functions | X | X | X | X | X | X | | | |
| NOTES: | <ol style="list-style-type: none"> 1. Should be performed by an authorized Harley-Davidson dealer, unless you have the proper tools, service data and are mechanically qualified. 2. Disassemble, lubricate and inspect every 30,000 miles (48,000 kilometers) 3. Perform annually. 4. Not all vehicles are equipped with spoke wheels. Consult appropriate topic in service manual. 5. Disassemble, lubricate and inspect every 20,000 miles (32,000 kilometers). 6. Change D.O.T. 4 fluid and flush brake system every two years. 7. Adjust at 500 miles (800 kilometers). | | | | | | | | | |